

FD4 Manual

User Documentation of the *Four-Dimensional Distributed Dynamic Data structures*.

Version fd4-2010-08-19

Developed at ZIH, TU Dresden, Germany

<http://www.tu-dresden.de/zih/clouds>

This work was funded by the German Research Foundation (DFG).

Matthias Lieber (matthias.lieber@tu-dresden.de)

Contents

| | | |
|----------|---|-----------|
| 1 | Introduction | 3 |
| 2 | Basic Data Structure | 4 |
| 2.1 | Variable Table | 4 |
| 2.2 | Block | 5 |
| 2.3 | Domain and Iterator | 5 |
| 2.4 | Cell-centered and Face-centered Variables | 5 |
| 2.5 | Accessing Variable Arrays | 5 |
| 2.6 | Accessing Variable Arrays with Ghosts | 6 |
| 2.7 | Adaptive Block Mode | 7 |
| 2.8 | Boundary Conditions | 7 |
| 3 | Parallelization and Coupling | 8 |
| 3.1 | Ghost Communication | 8 |
| 3.2 | Dynamic Load Balancing | 8 |
| 3.3 | Coupling | 9 |
| 4 | Building the FD4 Library | 10 |
| 4.1 | Prerequisites | 10 |
| 4.2 | Configuration | 10 |
| 4.3 | Build FD4 | 10 |
| 5 | User Interface Tutorial | 11 |
| 5.1 | Basics | 11 |
| 5.2 | Variable Table Definition | 11 |
| 5.3 | Domain Creation | 12 |
| 5.4 | Block Iteration | 13 |
| 5.5 | Ghost Cells | 14 |
| 5.6 | Ghost Data Exchange | 14 |
| 5.7 | Boundary Conditions | 17 |
| 5.8 | Adaptive Block Allocation | 17 |
| 5.9 | Dynamic Load Balancing | 17 |
| 5.10 | Coupling Interface | 17 |
| 5.11 | Data Utilities | 17 |
| 5.12 | Vis5D Output | 17 |
| 5.13 | NetCDF Output | 17 |

1 Introduction

The ***Four-Dimensional Distributed Dynamic Data structures*** (FD4) is a framework originally developed for the parallelization of spectral bin cloud models and their coupling to atmospheric models. Thus, the data structures are optimized for these kinds of model systems. To use FD4, models must basically meet the following requirements:

- Based on a 3D regular cartesian grid *without* local refinement (i.e. AMR)
- PDE calculations with data dependencies to a limited number of adjacent cells (stencil calculations)

Nevertheless, FD4 can be used for many other applications, especially if at least one of the following points applies:


- Many variables per grid cell (>100)
- Varying workload per grid cell (varying in time as well as space) which demands dynamic load balancing
- Multiphase model: Additional computations for a limited spatial subset of the grid (drops, clouds, combustion processes, flame fronts, etc.)
- Model system: FD4-based Model coupled to other model(s)

The basic features of FD4 are:

- Written in Fortran 95
- MPI parallelization (requires MPI-2)
- Block-based decomposition of a regular rectangular numerical grid
- Exchange of ghost cells (i.e. block boundaries, halo zones)
- Optimized for large number of variables per grid cell
- Dynamic load balancing with Hilbert space-filling curves and ParMETIS
- Dynamic adaption of grid allocation status according to spatial structures (multiphase models)
- Coupling interface
- Simple NetCDF and Vis5D output
- Scalability to 10 000s of cores

2 Basic Data Structure

FD4 consists of several Fortran 95 modules each providing different data structures and services. The basic data structure is constituted by the **Variable Table**, the **Block**, and the **Domain**:



2.1 Variable Table

The **Variable Table** is a user-provided table of all variables which should be managed by FD4. It contains entries for several variable properties:

- The variable's name (character string)
- The discretization type (cell-centered or face-centered to any of the spatial dimensions)
- The number of time steps to allocate for this variable
- The size of a 4th (non-spatial) dimension called bin (originates from the size-resolving bin discretization for detailed cloud models)
- A default value ("null")
- An optional threshold value, to indicate separated phases in multiphase models and allow adaptive block allocation

The index of the variable in the table is called **Variable Index** and is used as identifier. All variables are floating point variables of the same kind (single or double precision). Integer or other types are not provided.

2.2 Block

Based on the *Variable Table*, FD4 allocates the arrays holding the variables in each **Block**. The *Blocks* provide a 3D decomposition of the grid. *Blocks* are allowed to be of different size. The block decomposition is defined by one vector of block start indices for each dimension, or, for convenience, by specifying a number of blocks for each dimension.

The *Blocks* are contained in two data structures:

- **Block Tree:** A self-balancing binary tree (red-black tree) which provides logarithmic complexity for access to arbitrary *Blocks*. For fast iteration, this tree is combined with a linked list. The index of a *Block* in the *Block Tree* is derived from its position in the global grid by fast bit shifting operations.
- **Neighbor Pointers:** To access **Neighbor Blocks**, which is required for any kind of stencil computations, each *Block* contains pointers to its 6 *Neighbor Blocks*.


Note that not all *Blocks* may be present at a time: In a parallel run (which is the intended use of FD4!), the *Blocks* are distributed to the processes. For more details about parallelization refer to Section 3. Additionally, when running in **Adaptive Block Mode**, only a specific subset of the *Blocks* are present globally, refer to Section 2.7. Thus, a *Neighbor Block* may be: locally present, on a remote process, or not present on any process.

2.3 Domain and Iterator

The **Domain** is the central object in FD4. It contains all data to describe the numerical grid and the data structure of the allocated *Blocks*. The **Iterator** object allows to iterate through the local list of *Blocks* associated with the *Domain* and offers subroutines to access ghost cells, see Section 2.6.

2.4 Cell-centered and Face-centered Variables

Cell-centered variables are located in the center of a 3D grid cell, whereas face-centered variables are centered on the grid cell's surfaces which correspond a specified spatial dimension. Thus, three types of face-centered variables are possible. Note, that the grid for face variables is extended by one in the face dimension - for the global domain as well as for each *Block*:



As a consequence, two adjacent *Blocks* share copies of the same face variable at their boundary. This has consequences regarding consistency, see Section 5.6. The actual data arrays are allocated starting at index 1 for each dimension (block-local indexes).

One feature of FD4 is, that the data arrays are allocated without ghost cells (helo zones), which saves memory when small *Blocks* are used.

2.5 Accessing Variable Arrays

The variables are allocated in the *Blocks* as one 4D array per discretization type (cell-centered, x-face, y-face, z-face). The variables, their time steps, and their bins are mapped on the first

dimension, the three other dimensions are used for the spatial indexes.


A specific variable item of one *Block* is accessed as `block%ldata(f)%l(b,x,y,z)` with

- the face variable indicator f (0 for cell-centered, 1–3 for face-centered in x , y , z respectively)
- the variable, time steps, and bins encoded to b
- the block-local spatial indexes x , y , z

Since this is not straightforward, an array of pointers for variables and their time steps pointing to the corresponding sections in the actual data arrays is provided. The access is then via `block%fields(idx,st)%l(b,x,y,z)` with

- the variable index idx as defined by the *Variable Table*
- the time step index st (starting at 1)
- the bin b (1 for non-4D variables)
- the block-local spatial indexes x , y , z

This figure illustrates an example for the data structures:




Using the `block%fields` array, only grid cells of the local block can be accessed, but not grid cells of *Neighbor Blocks* (ghost cells).

2.6 Accessing Variable Arrays with Ghosts

The *Iterator* object contains the subroutine `fd4_iter_get_ghost` to access variables of the current *Block* including the boundaries of the 6 *Neighbor Blocks* (ghost cells). The variables are copied to a buffer array, which can then be used for stencil computations. The number of ghost cell rows is defined for each dimension when creating the domain. It is the same for all cell-centered variables. Access to face-centered variables of *Neighbor Blocks* is not implemented.

This figure shows an example in 2D:




Note, that only data of the 6 direct *Neighbor Blocks* (in 3D) are copied, not the data of the diagonal *Neighbor Blocks*. The resulting values in the area of the ghost cells depend on the state of each *Neighbor Block*:

- Neighbor is locally present: Data are copied directly from the *Neighbor Block* to the buffer array.

- Neighbor is present on a remote process: Data are copied from the ***Ghost Block*** - a copy of the remote *Block*'s boundary - to the buffer array. See Section 3.1.
- Neighbor is not present on any process: The corresponding section of the buffer array is filled with the default value of the variable(s).

2.7 Adaptive Block Mode


FD4 allows the dynamic adaption of the block allocation to spatial structures. It is useful for special multiphase applications when neither computations nor data are required for certain regions of the spatial grid. In this case, memory can be saved by not allocating the unused (***empty***) blocks. This mode, the so-called ***Adaptive Block Mode***, is only enabled if any of the variables in the *Variable Table* are threshold-variables, i.e. these variables have a threshold value. A *Block* is considered *empty* if in all its grid cells the values of all threshold-variables are less or equal than their corresponding threshold value. Based on this definition, FD4 decides which blocks to deallocate from the global block structure. Additionally, FD4 ensures that appropriate data are provided for the numerical stencil around non-*empty* cells. This mechanism also triggers the allocation of new blocks:



The actual block adaption (allocation of new *Blocks*, deallocation of unused *Blocks*) is carried out in the dynamic load balancing routine, see Section 3.2.

2.8 Boundary Conditions

Periodic boundary conditions are implemented straightforward in FD4 by periodic *Neighbor Pointers*. For non-periodic boundary conditions, ***Boundary Ghost Blocks*** are added for *Blocks* at the domain boundary. The *Boundary Ghost Blocks* have to be filled by the user, except for zero gradient boundary conditions, which are implemented in FD4. This figure shows the concept for periodic (left) and non-periodic (right) boundary conditions for an exemplary 2D domain (in *Adaptive Block Mode*):




3 Parallelization and Coupling

Parallelization of the FD4 grid is achieved by distributing the *Blocks* to the processes. Consequently, the total number of *Blocks* should be greater or equal than the number of processes.

3.1 Ghost Communication

Before performing stencil computations in parallel runs (which require the boundary of *Neighbor Blocks*, see Section 2.6), the boundaries have to be transferred between the processes. So-called **Communication Ghost Blocks** are allocated at process borders in the block decomposition to store the boundary of remote *Neighbor Blocks*. The **Ghost Communicator** object handles the update of the *Communication Ghost Blocks*. The *Ghost Communicator* is created for a specified set of variables and can be executed whenever necessary.

This figure shows an exemplary block decomposition for two processes and the *Communication Ghost Blocks*:



3.2 Dynamic Load Balancing

The dynamic load balancing in FD4 performs 3 major steps:


1. Determine if load balancing is necessary.
2. Calculate a new partitioning, i.e. mapping of *Blocks* to processes.
3. Migration and (De)allocation of *Blocks*.

Basically there are two situations for which load balancing is necessary: Firstly, when running in *Adaptive Block Mode*, *Blocks* may be added or removed from the global domain, which requires a new mapping of *Blocks* to processes. Secondly, if the workload of the *Blocks* changes non-uniformly, the load balance of the processes declines and more time is lost at synchronization points of the program. Of course, both reasons may also appear at the same time.

The workload of the *Blocks* is described by the **Block Weight**. The default value is the number of grid cells of the *Block*. If the workload does not exclusively depend on the number of grid cells, the *Block Weight* should be set to the actual computation time for each *Block*. If no *Blocks* were added or removed from the global domain, the decision whether load balancing is necessary or not depends on the load balance of the last time step (based on the *Block Weight*) and a specified load balance tolerance. Thus, it is possible to control how sensitive FD4 should react on emerging load imbalances. Instead of specifying a fixed tolerance, FD4 can also automatically decide whether load balancing is beneficial or not. This **Auto Mode**

requires that the *Block Weight* are set to the computation time. FD4 weighs the time lost due to imbalance against the time required for load balancing.

Two different methods for the calculation of the new partitioning are implemented in FD4: A graph-based approach using the ParMETIS library and a geometric approach using the Hilbert space-filling curve (SFC). Both methods are incremental, which means that the difference of successive partitionings is low to reduce migration costs. SFC partitioning is preferred since it executes much faster compared to ParMETIS. This figure shows a 2D Hilbert SFC and an exemplary partitioning derived from the curve:




3.3 Coupling

FD4 allows to couple models based on FD4 to external models, i.e. transfer variables between these models. The coupling interface has the following assumptions:

- Sequential coupling: Both models (FD4-based and external) work on the same set of processes and all processes perform computations for these models alternately.
- Same grid structure: Both models have the same grid structure, or at least the external model provides its coupling data matching the grid used in FD4.
- Block-based partitioning: The partitioning of the external model is based on rectangular blocks, but may be different than the partitioning in FD4.

The **Couple Context** is the description of the **Couple Arrays**, the data fields of the external model. Among other specifications, the position of each *Couple Array* in the global grid, the process owning this array, and the matching FD4 variable must be provided. Based on this description, FD4 computes the overlaps of each provided *Couple Array* with the *Blocks* and transmits the variables directly between the processes. FD4 is able to communicate coupling data in both directions: The **Put** operation sends variables from the external model to FD4 whereas **Get** sends variables from FD4 to the external model. This figure shows a *Put* operation from one single partition of an external model to the matching FD4 blocks:



In this example, two messages are sent, if none of the two receiving FD4 partitions belongs to the sender process of the external model. If the sender owns a receiving partition in FD4, the corresponding data is copied locally without sending a message.

The *Couple Context* concept allows to couple multiple external models to multiple FD4-based models. However, the direct coupling between two models based on FD4 is not implemented.

4 Building the FD4 Library

4.1 Prerequisites

Compiling and running FD4 requires:

- Unix / Linux system
- GNU make
- C and Fortran 95 compilers
- An MPI-2 implementation (for example [Open MPI](#) or [MPICH2](#))

Optional features of FD4 require additional external packages:

- The NetCDF library is required for NetCDF output. Parallel output is available with NetCDF4 only (if compiled with parallel HDF5). Serial output is possible with both NetCDF3 and NetCDF4. Note, that NetCDF output is currently not optimized in FD4.
Website: <http://www.unidata.ucar.edu/software/netcdf/>
- Compiled sources of Vis5D+ are required to write output to Vis5D files.
Website: <http://vis5d.sourceforge.net>
- ParMETIS is required for graph-based dynamic load balancing.
Website: <http://glaros.dtc.umn.edu/gkhome/metis/parmetis/overview/>

4.2 Configuration

- Create a configuration file for your system in the directory `config/`.
- You can use `conf.default` as a starting point or the other config files specific to some compilers.
- Name the config file `conf.<NAME>` or just overwrite `conf.default`.
- Optionally edit `config/fd4flags.in` to set some configuration flags for FD4, most notably `FD4_VERBOSE_LEVEL` (level 3 enables expensive runtime checks and has performance impact!).

4.3 Build FD4

- Type `make conf=<NAME>`.
 - You need GNU make; this may require calling `gmake` instead of `make` on certain systems.
 - If you name your config file `conf.default`, you can just type `make`.
- You can use parallel make to speed up the build process by calling, e.g.,
`make -j 4 conf=<NAME>`.
- This should build the library `libfd4.a`.
- To create multiple builds of FD4, use `./mkbuilddir.sh <DIR>` to create a new build directory (with its own configuration) and call `make` from there.

5 User Interface Tutorial

This chapter shows the user interface subroutines of FD4 by means of small examples. The example programs are contained in the FD4 package in the directory `tutorial`. They are numbered in the same order as the following sections. The complete documentation of the routines can be found in the FD4 package in `doc/index.html`.

5.1 Basics: 01_basics.F90

Include the module `fd4_mod` to your Fortran 95 source to make the FD4 interface available. FD4 defines kind type parameters for integer and real variables in `util/kinds.F90`:

| Name | Data type | Remarks |
|------------------|----------------|---|
| <code>i4k</code> | 4 byte integer | default integer type in FD4 |
| <code>i8k</code> | 8 byte integer | |
| <code>i_k</code> | 4 byte integer | |
| <code>r4k</code> | 4 byte real | type for grid variables, can be changed to <code>r4k</code> |
| <code>r8k</code> | 8 byte real | |
| <code>r_k</code> | 8 byte real | |

One of the basic utility functions is `gettime`, which returns the microseconds since 1970 as an 8 byte integer. It can be used to clock parts of the program.

```
program fd4_demo_basics

  use fd4_mod
  implicit none

  integer(i8k) :: time_now_us
  real(r8k)    :: time_now_s

  ! gettime is part of the FD4 utilities, calls C system function gettimeofday
  call gettime(time_now_us)
  time_now_s = real(time_now_us,r8k) / 1.e6_r8k

  write(*,'(A,F16.4)') 'seconds since 1970: ', time_now_s

end program fd4_demo_basics
```

5.2 Variable Table Definition: 02_vartab.F90

Each variable which should be managed by FD4 is defined by an entry in the *Variable Table*, an array of type `fd4_vartab`. See Section for a description.

```
program fd4_demo_vartab

  use fd4_mod
  implicit none

  ! these paramters are the indexes of the variables in the variable table
  integer, parameter :: varTmp = 1, varRho = 2, varQC = 3, varU = 4, varV = 5
  integer, parameter :: number_of_variables = 5
```

```

! this is the variable table
type(fd4_vartab) :: vartab(number_of_variables)

! fill the variable table for varTemp
vartab(varTmp)%name      = 'Temperature' ! name of the variable, at most 64 characters
vartab(varTmp)%nbins     = 1              ! number of bins = size of the 4th dimension
vartab(varTmp)%nsteps    = 2              ! number of time steps to allocate
vartab(varTmp)%dynamic   = .false.        ! currently unused
vartab(varTmp)%vnull     = 0.0_r8k        ! initial/default value
vartab(varTmp)%vthres    = FD4_NOTHRES    ! threshold value or FD4_NOTHRES
vartab(varTmp)%facevar   = 0              ! discretization type

! since the type fd4_vartab has default values for all components but the name,
! you can left out some definitions
vartab(varRho)%name      = 'Densitiy'
vartab(varRho)%nsteps   = 2

! but the most clearly method is to use the derived type constructors and
! arrange them as table with one variable per row
!
!               name, nb, st, unused, ini,          vthres, discret.
vartab(varQC) = fd4_vartab('Droplets', 12, 2, .false., 0.0,          0.0, FD4_CELLC )
vartab(varU)  = fd4_vartab( 'u Wind',  1, 1, .false., 0.0, FD4_NOTHRES, FD4_FACEX )
vartab(varV)  = fd4_vartab( 'v Wind',  1, 1, .false., 0.0, FD4_NOTHRES, FD4_FACEY )

write(*, '(5(A24,I4,I4,I3,E11.3,E11.3,I3,/))') vartab

end program fd4_demo_vartab

```

5.3 Domain Creation: 03_domain.F90

The *Domain* is described by the derived type `fd4_domain`. A *Domain* is created by calling `fd4_domain_create`, which needs the following inputs:

- number of *Blocks* in x, y, z
- lower and upper bounds of the grid in x, y, z
- *Variable Table*
- number of ghost cells in x, y, z
- periodic boundary conditions in x, y, z
- MPI communicator

Creating a *Domain* does not allocate any *Blocks*. Use `fd4_util_allocate_all_blocks` to allocate all *Blocks* balanced over all processes. The subroutine `fd4_domain_delete` removes all *Blocks* and frees all memory associated with the *Domain*.

```

program fd4_demo_domain

use fd4_mod
implicit none
include 'mpif.h'

! FD4 variable table
integer, parameter :: varTmp = 1, varRho = 2, varQC = 3, varU = 4, varV = 5
integer, parameter :: number_of_variables = 5
type(fd4_vartab) :: vartab(number_of_variables)
! FD4 domain
integer :: dsize(3,2), bnum(3), nghosts(3)
logical :: periodic(3)
type(fd4_domain) :: domain
! misc
integer :: rank, err

!! Create the variable table
!
!               name, nb, st, unused, ini,          vthres, discret.
vartab(varTmp) = fd4_vartab('Temperature', 1, 2, .false., 0.0, FD4_NOTHRES, FD4_CELLC )
vartab(varRho) = fd4_vartab( 'Densitiy',  1, 2, .false., 0.0, FD4_NOTHRES, FD4_CELLC )
vartab(varQC)  = fd4_vartab( 'Droplets', 12, 2, .false., 0.0, FD4_NOTHRES, FD4_CELLC )
vartab(varU)   = fd4_vartab( 'u Wind',  1, 1, .false., 0.0, FD4_NOTHRES, FD4_FACEX )

```

```

vartab(varV) = fd4_vartab( 'v Wind', 1, 1, .false., 0.0, FD4_NOTHRES, FD4_FACEY )

!! MPI Initialization
call MPI_Init(err)
call MPI_Comm_rank(MPI_COMM_WORLD,rank ,err)

!! Create the FD4 domain
dsize(1:3,1) = (/ 1, 1, 1/) ! grid start indices
dsize(1:3,2) = (/ 16, 16, 16/) ! grid end indices
bnum(1:3) = (/ 4, 4, 4/) ! number of blocks in each dimension
nghosts(1:3) = (/ 2, 2, 2/) ! number of ghost cells in each dimension
periodic(1:3) = .true. ! periodic boundaries
call fd4_domain_create(domain, bnum, dsize, vartab, nghosts, periodic, MPI_COMM_WORLD, err)
if(err/=0) then
  write(*,*) 'fd4_domain_create failed'
  call MPI_Abort(MPI_COMM_WORLD, 1, err)
end if

if(rank==0) write(*,'(A,I5)') 'number of allocated blocks: ', domain%blockcount

!! Allocate the blocks
call fd4_util_allocate_all_blocks(domain, err)

if(rank==0) write(*,'(A,I5)') 'number of allocated blocks: ', domain%blockcount

!! Delete the domain and finalize MPI
call fd4_domain_delete(domain)
call MPI_Finalize(err)

end program fd4_demo_domain

```

If you have compiled FD4 with `FD4_VERBOSE_LEVEL 2` or higher, FD4 should print something like this:

```

[FD4:0000] created new fd4_domain:
[FD4:0000] dim      start      end  blocks   blkksz  ghosts  per.bd
[FD4:0000]   x         1        16        4    4.00      2      T
[FD4:0000]   y         1        16        4    4.00      2      T
[FD4:0000]   z         1        16        4    4.00      2      T
[FD4:0000] max. number of blocks:   64
[FD4:0000] Hilbert SFC level:       3
[FD4:0000] number of MPI processes: 2
[FD4:0000] block pool stacks:       4
[FD4:0000] block pool total size:  184
[FD4:0000] adaptive block mode:     F
[FD4:0000] variable table:
[FD4:0000] id  nbins  nsteps  dyn    vnull  threshld  face  name
[FD4:0000]  1      1      2    F    0.0E+00    -    -  Temperature
[FD4:0000]  2      1      2    F    0.0E+00    -    -  Densitiy
[FD4:0000]  3     12      2    F    0.0E+00    -    -  Droplets
[FD4:0000]  4      1      1    F    0.0E+00    -    x   u Wind
[FD4:0000]  5      1      1    F    0.0E+00    -    y   v Wind
number of allocated blocks:    0
number of allocated blocks:    64

```

5.4 Block Iteration: 04_iterator.F90

To access the *Blocks* a process owns, FD4 offers an *Iterator* which iterates over all *Blocks* of the *Domain* in unspecified order. To read or write the data fields of a *Block*, use the `block%fields(idx,st)%l(b,x,y,z)` approach as described in Section 2.5. Note that you cannot access the ghost cells in this way, see Section 5.5. A *Block* iteration loop looks as follows:

```

!! Loop over all blocks of the domain and intialize the temperature
call fd4_iter_init(domain, iter)
do while(associated(iter%cur))
  write(*,'(A,I4,A,3(I3))') 'rank ',rank,' iterates to block at (x, y, z) ',iter%cur%pos

```

```

! get offset from domain indexes to block-local indexes
call fd4_iter_offset(iter, offset)
! loop over block's grid cells
do z=1,iter%cur%ext(3)
  do y=1,iter%cur%ext(2)
    do x=1,iter%cur%ext(1)
      ! get z coordinate of this grid cell in global coordinates
      gz = offset(3) + z
      ! set temperature depending on global z coordinate
      iter%cur%fields(varTmp,1)%l(1,x,y,z) = 295.0 + f * REAL(gz)
    end do
  end do
end do
! go to next block
call fd4_iter_next(iter)
end do

```

5.5 Ghost Cells: 05_ghosts.F90

To get variables from a *Block* with ghost cells from the six *Neighbor Blocks*, use the subroutine `fd4_iter_get_ghost`. It copies the current *Block*'s data and the boundary of *Neighbor Blocks* to a 4D buffer array. See Section 2.6 for more details about accessing ghost cells. The buffer array must be large enough to hold the spatial bounds of the *Block* and the 4th dimension of the variables. Note that the 4th dimension is in fact the 0th dimension: it comes first. To get the bounds of the largest *Block* in the *Domain*, use the subroutine `fd4_domain_max_bext`. This example shows how to allocate a buffer array for a variable with a 4th dimension and how to read the ghost cells:

```

!! Allocate the buffer array for a single block with ghost cells
! get the max block extent (bext) including ghost cells
call fd4_domain_max_bext(domain, bext(1:3), .true.)
bext(0) = vartab(varQC)%nbins ! 4th dimension
! allocate the buffer array with interior grid cells starting at 1
allocate( buffer(bext(0),-1:bext(1)-2,-1:bext(2)-2,-1:bext(3)-2) )
buffer = 0.0_r_k

!! Initialize time step indicators
now = 1
new = 2

!! Loop over all blocks of the domain and do some sort of computations
call fd4_iter_init(domain, iter)
do while(associated(iter%cur))
  ! get droplets with ghost cells from current block at time step 'now'
  call fd4_iter_get_ghost(iter, varQC, now, bext, buffer)
  ! loop over block's grid cells
  do z=1,iter%cur%ext(3)
    do y=1,iter%cur%ext(2)
      do x=1,iter%cur%ext(1)
        ! do some stencil computations, update 'new' values
        iter%cur%fields(varQC,new)%l(:,x,y,z) = buffer(:,x,y,z) + &
          ( f(-2) * buffer(:,x-2,y,z) + f(-1) * buffer(:,x-1,y,z) + f(0) * buffer(:,x,y,z) &
            + f(1) * buffer(:,x+1,y,z) + f(2) * buffer(:,x+1,y,z) ) * dt
        ! ...
      end do
    end do
  end do
  call fd4_iter_next(iter)
end do

```

5.6 Ghost Data Exchange: 06_heat.F90

Three functions are required to perform ghost communication: `fd4_ghostcomm_create`, `fd4_ghostcomm_exch`, and `fd4_ghostcomm_delete`.

Here is a complete demo application, it solves the heat conduction equation in 3D.

```

program fd4_demo_heat

  use fd4_mod
  implicit none
  include 'mpif.h'

  !! Setup parameters
  real, parameter :: radius = 0.5           ! rel. radius of initial heat perturbation
  integer, parameter :: grid(3) = 32       ! number of grid cells for x, y, z
  real(r_k), parameter :: ds(3) = 1.0      ! grid cell size for x, y, z
  real(r_k), parameter :: dt = 0.1         ! time step size
  real(r_k), parameter :: dthetastop = 1.d-3 ! exit condition for dthetamax

  ! FD4 variable table
  type(fd4_vartab) :: vartab(1)
  integer, parameter :: THETA = 1
  ! FD4 domain
  type(fd4_domain) :: domain
  integer :: dsize(3,2), bnum(3), nghosts(3)
  logical :: periodic(3)
  ! FD4 iterator
  type(fd4_iter) :: iter
  ! FD4 ghost communication
  type(fd4_ghostcomm) :: ghostcomm(2)
  ! misc
  integer :: rank, err, bext(0:3)
  integer :: offset(3), x, y, z, now, new, step
  real(r_k), allocatable :: buf(:, :, :, :)
  real(r_k) :: dtheta, dthetamax, dthetamax_global
  real :: global_pos(3), cr

  !! MPI Initialization
  call MPI_Init(err)
  call MPI_Comm_rank(MPI_COMM_WORLD, rank, err)

  !! Create the FD4 variable table
  !! (only one cell-centered variable 'theta' with 2 time steps)
  !           name, nb, st, unused, ini,      vthres, discret.
  vartab(THETA) = fd4_vartab('theta', 1, 2, .false., 0.0, FD4_NOTHRES, FD4_CELLC )

  !! Create the FD4 domain
  dsize(1:3,1) = (/1, 1, 1/) ! grid start indices
  dsize(1:3,2) = grid(1:3)   ! grid end indices
  bnum(1:3) = grid(1:3) / 4   ! number of blocks in each dimension
  nghosts(1:3) = (/1, 1, 1/) ! number of ghost cells in each dimension
  periodic(1:3) = .true.     ! periodic boundaries
  call fd4_domain_create(domain, bnum, dsize, vartab, nghosts, periodic, MPI_COMM_WORLD, err)
  if(err/=0) then
    write(*,*) rank, ': fd4_domain_create failed'
    call MPI_Abort(MPI_COMM_WORLD, 1, err)
  end if

  !! Allocate the blocks of the domain
  call fd4_util_allocate_all_blocks(domain, err)

  !! Allocate the buffer array for a single block with ghost cells
  call fd4_domain_max_bext(domain, bext(1:3), .true.)
  bext(0) = 1 ! 4th dimension not used here
  allocate( buf(bext(0), 0:bext(1)-1, 0:bext(2)-1, 0:bext(3)-1) )
  buf = 0.0_r_k

  !! Initialize time step indicators
  now = 1
  new = 2

  !! Initialize theta with a spherical heat perturbation
  call fd4_iter_init(domain, iter)
  do while(associated(iter%cur))
    ! offset from domain indexes to block-local indexes
    call fd4_iter_offset(iter, offset)
    ! loop over block's grid cells
    do z=1, iter%cur%ext(3)
      do y=1, iter%cur%ext(2)
        do x=1, iter%cur%ext(1)
          ! get global coordinates of this grid cell and scale to [0,1]

```

```

global_pos(1) = REAL( offset(1) + x - 1 ) / REAL(dsize(1,2) - 1)
global_pos(2) = REAL( offset(2) + y - 1 ) / REAL(dsize(2,2) - 1)
global_pos(3) = REAL( offset(3) + z - 1 ) / REAL(dsize(3,2) - 1)
! distance from domain center to current grid cell
cr = sqrt( (global_pos(1)-0.5)**2+(global_pos(2)-0.5)**2+(global_pos(3)-0.5)**2 )
if(cr < radius) then
  iter%cur%fields(THETA,now)%l(1,x,y,z) = 2.0_r_k * cos(3.14159*cr/(2*radius))
end if
end do
end do
end do
call fd4_iter_next(iter)
end do

!! Create ghost communicator for variable THETA (one for each time level)
call fd4_ghostcomm_create(ghostcomm(1), domain, 1, (/THETA/), (/1/), err)
call fd4_ghostcomm_create(ghostcomm(2), domain, 1, (/THETA/), (/2/), err)

!! Time stepping loop
do step=1,10000

  ! exchange ghost cells for time level 'now'
  call fd4_ghostcomm_exch(ghostcomm(now), err)
  dthetamax = 0

  ! iterate over all local blocks
  call fd4_iter_init(domain, iter)
  do while(associated(iter%cur))
    ! get theta with ghost cells from current block
    call fd4_iter_get_ghost(iter, THETA, now, bext, buf)
    ! loop over block's grid cells
    do z=1,iter%cur%ext(3)
      do y=1,iter%cur%ext(2)
        do x=1,iter%cur%ext(1)
          !
          ! ( d2T d2T d2T )
          ! theta_new = theta_now + ( --- + --- + --- ) * dt
          ! ( dx2 dy2 dz2 )
          ! calculate dtheta
          dtheta = ( buf(1,x-1,y,z) + buf(1,x+1,y,z) - 2*buf(1,x,y,z) ) / (ds(1) * ds(1)) &
                  + ( buf(1,x,y-1,z) + buf(1,x,y+1,z) - 2*buf(1,x,y,z) ) / (ds(2) * ds(2)) &
                  + ( buf(1,x,y,z-1) + buf(1,x,y,z+1) - 2*buf(1,x,y,z) ) / (ds(3) * ds(3))
          ! set updated theta value
          iter%cur%fields(THETA,new)%l(1,x,y,z) = buf(1,x,y,z) + dtheta * dt
          ! save max theta for the exit condition
          dthetamax = max(abs(dtheta), dthetamax)
        end do
      end do
    end do
    call fd4_iter_next(iter)
  end do

  if(rank==0 .and. mod(step,100)==0) write(*,'(A,I5)') 'step ',step

  ! check exit condition
  call MPI_Allreduce(dthetamax, dthetamax_global, 1, MPI_R_K, MPI_MAX, MPI_COMM_WORLD, err)
  if( dthetamax_global < dthetastop ) then
    if(rank==0) write(*,'(A,I5)') 'exit condition reached at step ',step
    exit
  end if

  ! swap time step indicators
  now = 3 - now
  new = 3 - new

end do

!! Delete the ghost communicator and the domain, finalize MPI
call fd4_ghostcomm_delete(ghostcomm(1))
call fd4_ghostcomm_delete(ghostcomm(2))
call fd4_domain_delete(domain)
call MPI_Finalize(err)

end program fd4_demo_heat

```


5.7 Boundary Conditions

5.8 Adaptive Block Allocation

5.9 Dynamic Load Balancing

5.10 Coupling Interface

5.11 Data Utilities

5.12 Vis5D Output

5.13 NetCDF Output